



## Accessories for Hope/Carnfeldt processors



### Rack hoist

The rack hoist enables one person to lift out the racks from the processor for regular maintenance and cleaning. The rack hoist is mounted on the side of the processor and is easy to operate. Standard height: 179-209 cm.

### Order no.

EG 751 : 315017  
EG 901 : 320017  
EG 1371 : 340009  
EG 750/EP 750 : 316020  
EG 900/EP 900 : 320019

### Extra

Rack hoist fixing bracket set:

### Order no.

All two-frame models : 305199

Lifting bar for rack hoist:

EG 751 : 128752  
EG 901 : 320056  
EG 1371 : 155757



### Drip tray for racks

Prevents spillage of chemicals when removing racks from the processor for cleaning.

### Order no.

EG 751/EG 750/EP 750 : 315043  
EG 901/EG 902 : 320043  
EG 900/EP 900 : 320043  
EG 1371 : 340043  
EG 1661 : 350643



### Floor drip tray

By initially placing the processor on a drip tray spillage of chemistry on the floor is prevented.

### Order no.

EG 750/EP 750 : 315281  
EG 751 : 320291  
EG 901/EG 902 : 320291  
EG 900/EP 900 : 320291  
EG 1371 : 155884



### Replenishment container

Repl. container for dev. and fix.  
Available in 30 l and 70 l.

### Order no.

Dev. repl. container (30 l) : 217049  
Fix. repl. container (30 l) : 217059  
Dev. repl. container (70 l) : 68844  
Fix. repl. container (70 l) : 68521



### Repl. container 30 l with low level alarm sensor

Repl. container for dev. and fix., act. and stab. with low level alarm sensor.

### Order no.

For all EG models  
Dev. repl. container : 305549  
Fix. repl. container : 305559

### Waste container 30 l with alarm sensor for max. level

### Order no.

For all models : 305569



### Level alarm sensor (low)

When the sensor is connected to the processor's control box it starts an alarm and stops the replenish pumps when the level in the replenishment

### Order no.

All EG models : 305529



## Accessories for Hope/Carnfeldt processors

---



### Level alarm sensor (full)

If the level in the waste container is too high the sensor starts and alarm and stops the replenish pumps.

### Order no.

All EG models : 305529



### Chemical Mixer

The chemical mixer will mix concentrated liquid developer and fixer with water in a pre-adjusted mixing ratio and feed it to the processing tank of the processor as replenishment.

### Order no.

For all models: : 305581



### Installation kit

To ease installation a complete installation kit containing all needed tubes, cable, hoses etc. is available.

### Order no.

For all models : 217659



### Mobile rack hoist

The mobile rack hoist enables one person to lift out the racks from the processor for regular maintenance and cleaning. It includes a drip tray to prevent spillage of chemicals when transporting the racks to the sink for cleaning. Standard height: 222-242 cm. The rack hoist can be parked over the processor.

### Order no.

EG 1371 : 155738

EG 1661 : 350738



### Daylight inlet kit

Allows daylight film to be feed manually into the processor from the top of the processor. Often used when the processor is installed through darkroom wall. The system includes a control unit with no-feed lamp, manual start and manual replenishment.

### Order no.

EG 750 Dolev 250/450/4press: 316709

EG 751 Dolev 450/4pressV : 315709

EG 900 Dolev 800V : 320713

EG 901 Dolev 800V : 320712

EG 900 Purup B1/B2 : 320711

EG 901 Purup B1/B2 : 320708

EG 1661 : 350709